

PiezoPiE861 Tango Cpp Class

Contents :

- [Description](#)
 - [Properties](#)
 - [Commands](#)
 - [State](#)
 - [Status](#)
 - [MoveRelative](#)
 - [CheckDriftStability](#)
 - [StopMove](#)
 - [ResetMotor](#)
 - [Calibrate](#)
 - [Attributes](#)
 - [Position](#)
 - [ServoMode](#)
 - [Error](#)
 - [UnitLimitMin](#)
 - [UnitLimitMax](#)
 - [Version](#)
 - [SlewRate](#)
 - [SettleWindow](#)
 - [SettleTime](#)
 - [States](#)
-

PiezoPiE861 Class Identification :

Contact : at mail.desy.de - tnunez
Class Family : Motion
Platform : Unix Like
Bus : Socket
Manufacturer : Physik Instrumente (PI)
Manufacturer ref. : E861

PiezoPiE861 Class Inheritance :

- [Tango::DeviceImpl](#)
 - PiezoPiE861

PiezoPiE861 Class Description :

PiezoPiE861 Properties :

There is no class properties

Device Properties			
Name	Description	Type	Default Value
SocketDS		String	none
AxisNumber	Axis Number (from 1 to 3)	int	none

PiezoPiE861 Class Commands				
Name	Input type	Output type	Level	Description
State	DEV_VOID	DEV_STATE	OPERATOR	This command gets the device state (stored in its <i>device_state</i> data member) and returns it to the caller.
Status	DEV_VOID	CONST_DEV_STRING	OPERATOR	This command gets the device status (stored in its <i>device_status</i> data member) and returns it to the caller.
MoveRelative	DEV_DOUBLE	DEV_LONG	OPERATOR	None.
CheckDriftStability	DEV_DOUBLE	DEV_DOUBLE	OPERATOR	None.
StopMove	DEV_VOID	DEV_VOID	OPERATOR	None.
ResetMotor	DEV_VOID	DEV_VOID	OPERATOR	Reset master unit.
Calibrate	DEV_DOUBLE	DEV_VOID	OPERATOR	Only for compatibility reasons. Does nothing.

Command State :

This command gets the device state (stored in its *device_state* data member) and returns it to the caller.



State Definition		
Input Argument	Tango::DEV_VOID	none.
Output Argument	Tango::DEV_STATE	State Code
DisplayLevel	OPERATOR	..
Inherited	true	..
Abstract	false	..
Polling Period	Not polled	..
Command allowed for	All states	..

Command Status :

This command gets the device status (stored in its *device_status* data member) and returns it to the caller.

Status Definition		
Input Argument	Tango::DEV_VOID	none.
Output Argument	Tango::CONST_DEV_STRING	Status description
DisplayLevel	OPERATOR	..
Inherited	true	..
Abstract	false	..
Polling Period	Not polled	..
Command allowed for	All states	..

Command MoveRelative :

MoveRelative Definition		
Input Argument	Tango::DEV_DOUBLE	
Output Argument	Tango::DEV_LONG	
DisplayLevel	OPERATOR	..
Inherited	false	..
Abstract	false	..

Polling Period	Not polled	..
Command NOT allowed for	• MOVING	..

Command CheckDriftStability :

CheckDriftStability Definition		
Input Argument	Tango::DEV_DOUBLE	
Output Argument	Tango::DEV_DOUBLE	
DisplayLevel	OPERATOR	..
Inherited	false	..
Abstract	false	..
Polling Period	Not polled	..
Command NOT allowed for	• MOVING	..

Command StopMove :

StopMove Definition		
Input Argument	Tango::DEV_VOID	
Output Argument	Tango::DEV_VOID	
DisplayLevel	OPERATOR	..
Inherited	false	..
Abstract	false	..
Polling Period	Not polled	..
Command allowed for	All states	..

Command ResetMotor :

Reset master unit.

ResetMotor Definition		
Input Argument	Tango::DEV_VOID	
Output Argument	Tango::DEV_VOID	
DisplayLevel	OPERATOR	..
Inherited	false	..
Abstract	false	..
Polling Period	Not polled	..
Command allowed for	All states	..

Command Calibrate :

Only for compatibility reasons. Does nothing.

Calibrate Definition		
Input Argument	Tango::DEV_DOUBLE	
Output Argument	Tango::DEV_VOID	
DisplayLevel	OPERATOR	..
Inherited	false	..
Abstract	false	..
Polling Period	Not polled	..
Command allowed for	All states	..

PiezoPiE861 Class Attributes

--	--	--	--	--	--	--	--

Name	Inherited	Abstract	Attr. type	R/W type	Data type	Level	Description
Position	false	false	Scalar	READ_WRITE	Tango::DEV_DOUBLE	OPERATOR	
ServoMode	false	false	Scalar	READ_WRITE	Tango::DEV_LONG	OPERATOR	
Error	false	false	Scalar	READ	Tango::DEV_STRING	OPERATOR	
UnitLimitMin	false	false	Scalar	READ_WRITE	Tango::DEV_DOUBLE	OPERATOR	
UnitLimitMax	false	false	Scalar	READ_WRITE	Tango::DEV_DOUBLE	OPERATOR	
Version	false	false	Scalar	READ	Tango::DEV_STRING	OPERATOR	
SlewRate	false	false	Scalar	READ_WRITE	Tango::DEV_DOUBLE	OPERATOR	
SettleWindow	false	false	Scalar	READ	Tango::DEV_LONG	OPERATOR	Settle window for close loop operation,
SettleTime	false	false	Scalar	READ	Tango::DEV_DOUBLE	OPERATOR	Settle time for close loop operation

There is no dynamic attribute defined.

Attribute Position :

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_DOUBLE
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set

Attribute Properties	
label	
unit	mum
standard unit	
display unit	
format	
max_value	
min_value	
max_alarm	
min_alarm	
max_warning	
min_warning	

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set

Read allowed for	All states
Write allowed for	All states

delta_time	
delta_val	

Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	Not set

Attribute ServoMode :

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_LONG
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	true
Write hardware at init.	true
Read allowed for	All states
Write allowed for	All states

Attribute Properties	
label	
unit	
standard unit	
display unit	
format	
max_value	
min_value	
max_alarm	
min_alarm	
max_warning	
min_warning	
delta_time	
delta_val	

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	Not set

Attribute Error :

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ
Data Type	Tango::DEV_STRING
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set
Read allowed for	All states

Attribute Properties	
label	
unit	
standard unit	
display unit	
format	
max_value	
min_value	
max_alarm	
min_alarm	
max_warning	
min_warning	
delta_time	
delta_val	

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	Not set

Attribute UnitLimitMin :

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_DOUBLE
Display Level	OPERATOR
Inherited	false
Abstract	false

Attribute Properties	
label	
unit	
standard unit	
display unit	
format	
max_value	
min_value	

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set

Polling Period	Not polled
Memorized	true
Write hardware at init.	true
Read allowed for	All states
Write allowed for	All states

max_alarm	
min_alarm	
max_warning	
min_warning	
delta_time	
delta_val	

Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	Not set

Attribute UnitLimitMax :

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_DOUBLE
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	true
Write hardware at init.	true
Read allowed for	All states
Write allowed for	All states

Attribute Properties	
label	
unit	
standard unit	
display unit	
format	
max_value	
min_value	
max_alarm	
min_alarm	
max_warning	
min_warning	
delta_time	
delta_val	

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	Not set

Attribute Version :

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ
Data Type	Tango::DEV_STRING
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set
Read allowed for	All states

Attribute Properties	
label	
unit	
standard unit	
display unit	
format	
max_value	
min_value	
max_alarm	
min_alarm	
max_warning	
min_warning	
delta_time	
delta_val	

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	Not set

Attribute SlewRate :

Attribute Definition	
Attribute Type	Scalar

Attribute Properties	
label	
	physical

Attribute Event Criteria	
Periodic	Not set

R/W Type	READ_WRITE
Data Type	Tango::DEV_DOUBLE
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set
Read allowed for	All states
Write allowed for	All states

unit	units/s
standard unit	
display unit	
format	
max_value	
min_value	
max_alarm	
min_alarm	
max_warning	
min_warning	
delta_time	
delta_val	

Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	Not set

Attribute SettleWindow :

Settle window for close loop operation,

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ
Data Type	Tango::DEV_LONG
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set

Attribute Properties	
label	
unit	counts
standard unit	
display unit	
format	
max_value	
min_value	
max_alarm	
min_alarm	
max_warning	
min_warning	

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set

Read allowed for	All states
------------------	------------

delta_time	
delta_val	

Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	Not set

Attribute SettleTime :

Settle time for close loop operation

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ
Data Type	Tango::DEV_DOUBLE
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set
Read allowed for	All states

Attribute Properties	
label	
unit	s
standard unit	
display unit	
format	
max_value	
min_value	
max_alarm	
min_alarm	
max_warning	
min_warning	
delta_time	
delta_val	

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	Not set

PiezoPiE861 Class States

Name	Description
ON	
MOVING	
FAULT	