

SardanaStarter Tango Cpp Class

Contents :

- [Description](#)
- [Properties](#)
- [Commands](#)
 - [State](#)
 - [Status](#)
 - [StartSardana](#)
 - [StopSardana](#)
- [Attributes](#)
 - [ConfigFile](#)
- [States](#)

SardanaStarter Class Identification :

Contact : at mail.desy.de - tnunez
Class Family : Miscellaneous
Platform : Unix Like
Bus : Not Applicable
Manufacturer : none
Manufacturer ref. :

SardanaStarter Class Inheritance :

- [Tango::DeviceImpl](#)
 - SardanaStarter

SardanaStarter Class Description :

Server for starting Pool and MacroServer

SardanaStarter start tool Device Description

SardanaStarter Class

SardanaStarter Properties :

There is no class properties

Device Properties			
Name	Description	Type	Default Value
DefaultConfigFile		String	none

SardanaStarter Class Commands				
Name	Input type	Output type	Level	Description
State	DEV_VOID	DEV_STATE	OPERATOR	This command gets the device state (stored in its <i>device_state</i> data member) and returns it to the caller.
Status	DEV_VOID	CONST_DEV_STRING	OPERATOR	This command gets the device status (stored in its <i>device_status</i> data member) and returns it to the caller.
StartSardana	DEV_VOID	DEV_VOID	OPERATOR	None.
StopSardana	DEV_VOID	DEV_VOID	OPERATOR	None.

Command State :

This command gets the device state (stored in its *device_state* data member) and returns it to the caller.

State Definition		
Input Argument	Tango::DEV_VOID	none.
Output Argument	Tango::DEV_STATE	State Code
DisplayLevel	OPERATOR	..
Inherited	true	..
Abstract	true	..
Polling Period	Not polled	..
Command allowed for	All states	..

Command Status :

This command gets the device status (stored in its *device_status* data member) and returns it to the caller.

Status Definition		
Input Argument	Tango::DEV_VOID	none.
Output Argument	Tango::CONST_DEV_STRING	Status description
DisplayLevel	OPERATOR	..
Inherited	true	..
Abstract	true	..
Polling Period	Not polled	..
Command allowed for	All states	..

Command StartSardana :

StartSardana Definition		
Input Argument	Tango::DEV_VOID	
Output Argument	Tango::DEV_VOID	

DisplayLevel	OPERATOR	..
Inherited	false	..
Abstract	false	..
Polling Period	Not polled	..
Command allowed for	All states	..

Command StopSardana :

StopSardana Definition		
Input Argument	Tango::DEV_VOID	
Output Argument	Tango::DEV_VOID	
DisplayLevel	OPERATOR	..
Inherited	false	..
Abstract	false	..
Polling Period	Not polled	..
Command allowed for	All states	..

SardanaStarter Class Attributes							
Name	Inherited	Abstract	Attr. type	R/W type	Data type	Level	Description
ConfigFile	false	false	Scalar	READ_WRITE	Tango::DEV_STRING	OPERATOR	

There is no dynamic attribute defined.

Attribute ConfigFile :

Attribute Definition	
Attribute Type	Scalar
R/W Type	READ_WRITE
Data Type	Tango::DEV_STRING
Display Level	OPERATOR
Inherited	false
Abstract	false
Polling Period	Not polled
Memorized	Not set
Read allowed for	All states
Write allowed for	All states

Attribute Properties	
label	
unit	
standard unit	
display unit	
format	
max_value	
min_value	
max_alarm	
min_alarm	
max_warning	
min_warning	
delta_time	
delta_val	

Attribute Event Criteria	
Periodic	Not set
Relative Change	Not set
Absolute Change	Not set
Archive Periodic	Not set
Archive Relative Change	Not set
Archive Absolute Change	Not set
Push Change event by user code	false
Push Archive event by user code	false
Push DataReady event by user code	Not set

SardanaStarter Class States	
Name	Description
STANDBY	Pool and MacroServer are not running.
ON	Pool and Macro Server running.
FAULT	